

# Precision Square Liners

## Read before installing:

**Do not remove the protective blue film until you are ready to grout!** This will prevent scratching.

**Cut the liners with a hacksaw.** Lubricate the saw blade with 3-in-1 Oil or WD-40. Use a miter box to keep your cuts straight. Remove any metal burrs with a light stroke of very fine sandpaper.

**Keep grout lines as thin as possible, preferably 1/16-inch or less.**

**Use thinset adhesive.** To insure a good bond, rough up the back of the tiles with coarse sandpaper.

**After the thinset has dried, remove the blue film.** If the brass appears spotty, do not worry! The grout will act as a mild abrasive which will clean and slightly polish the brass.

**Use unsanded grout** (unless the installation absolutely requires grout lines of 1/8-inch or more).

**Grout release is not necessary.**

## Cleaning notes

**Avoid abrasive and acid-based cleaning agents on both stainless steel and brass.**

**To restore brass to its original brightness,** you can clean it with a mild vinegar solution (1 part vinegar, 5 parts water).

**To retard the natural patina on brass** and minimize fingerprints, apply a very thin layer of Renaissance Microcrystalline Wax (available from Amazon).

**When cleaning with vinegar or applying wax** use a soft cloth and be careful not to rub the soiled cloth onto the grout.